

4 Quadrant Bipolar Power Supply

Model 2510 – 12 amps

General Description

The MCOR 12 system is a 16-channel precision magnet driver, capable of providing bi-polar output currents in the range from -12A to +12A. The output current can be adjusted smoothly through zero. A single, unregulated bulk power supply provides the main DC power for the entire crate. The MCOR system employs

a modular architecture, so that any individual channel is serviceable without disturbing the operation of adjacent channels in the same crate.

Features

- Proven member of a modular Power Module family, more than 800 units are in service
- Precision-regulated Bi-Polar output provides up to +12 to -12 Amps for Magnet loads.
- Smooth operation through zero amps output current, no "Crossover" problems.



- All 2510 MCOR12 Power Modules are identical and interchangeable, and can be used in any application within its ratings. When a module is replaced, the Programming Card is plugged into the replacement module.
- Has two high-precision measurements of output current; one is used to close the regulation control loop, the other provides an independent monitoring signal to the Crate Interface Card.
- Fault sensing circuitry in the module sets a Fault Latch which inhibits the output.
- A (momentary) Sync input signal inhibits MOSFET switching when it is active (high); this eliminate switching noise "feed-through " from the Bulk Power Supply to the AC power lines. This feature reduces power line noise during sensitive analog signal measurements.

Applications

- Particle accelerator beams
- Industrial Robotics
- Motor control
- Medical equipment

For ordering information visit us online at **bira.com** or call **505-881-8887**

Specifications

Parameter	Min	Typ	Max	Unit
DC Mains Input Range	20		50	V
Output polarity Nominal Output Current Range Maximum Fault Current	0	Bipolar	12 15	A A
Load Capacitance Range (For Stable Operation)	0		50	uF
Operating Temperature	15		65	°C

Programming Card

Each magnet design has a unique inductance and frequency characteristic, and in addition each corrector installation has a unique cable plant resistance and maximum current rating.

In order to provide "custom-tailored" service to each corrector magnet, yet retain a high degree of modularity and consistency in the driver design, each MCOR 12 power module accommodates a small programming (PGM) card. This card contains a set of passive components that match several important characteristics of power module to its corrector magnet, including:

- IVA (output current vs. SAM voltage) determined by R101 R=300,000/ full-scale output current
- DVI (DAC voltage vs. output current) determined by R102
 R=300,000/ full-scale output current
- Tuning compensation values C101 (pole), R103 (zero)
- IMMO (maximum output current limit) determined by R104 R=3,000 ohm for 7.5 max output R=20,000 ohm for 12A max output R=OPEN CKT for 15A max output
- Internal or external sync selection

It is important to note that all MCOR 12 power modules are identical and nterchangeable. Every power module is capable of any full-scale current rating, as dictated by the plug-in PGM card that "piggybacks" on the power module. The PGM card is the only item that changes from slot to slot, giving the power module a tailored response to its corrector magnet. Each PGM card is labeled with the building, rack level and slot to which it belongs. When a power module is replaced, the programming card is removed from the old power module and installed on the new one, preserving the tailored response for that corrector magnet.

Bi Ra Systems - Tel: (505) 881-8887 • Fax: (505) 888-0651 • www.bira.com 2410 Midtown PL NE – Suite A – Albuquerque NM 87107, United States of America



© 2007 BiRa Systems Inc. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.